Access identification and preparation

1. Remove the Access stainless-steel twist-lock lid following site access rules. In FieldPass, scan the point-specific QR on the grey foam on the underside of the lid. Check the site and point match.

2. If the label cannot be read, stop assigning records. Send the site, position and visible label details to support.

Stop if electrical equipment, roof access or structural damage makes inspection unsafe. Follow the site safety rules.

Still unresolved? Send support the object, device, last successful time, visible error and completed checks.